

HIGH TEMPERATURE DECOMPOSITION OF ALMANDINE AND PYROPE IN REDUCING ATMOSPHERE

C. Aparicio, J. Filip, M. Mašláň

Centre for Nanomaterial Research, Olomouc, Czech Republic

Thermal decomposition of two garnets of near end-member composition – almandine $(\text{Fe}_{2.85}\text{Mg}_{0.15})(\text{Al}_{1.99})\text{Si}_{2.99}\text{O}_{12}$ and pyrope $(\text{Mg}_{2.22}\text{Fe}_{0.47}\text{Ca}_{0.33})(\text{Cr}_{0.11}\text{Fe}_{0.06}\text{Al}_{1.81})\text{Si}_{2.98}\text{O}_{12}$ – has been carried out in reducing atmosphere (forming gas: 10% of H_2 in N_2). High-temperature behavior of both samples was monitored using of simultaneous thermogravimetry and differential scanning calorimetry (heating rate of 10 °C/min). The decomposition of almandine and pyrope turned out to proceed at slightly different temperatures above 1000 °C. Subsequently, two series of samples were prepared based on results of thermal analysis: almandine (ALM) heated up to 950 °C, 1070 °C and 1200 °C, and pyrope (PY) heated up to 1000 °C, 1100 °C, 1125 °C and 1200 °C. The identification of the decomposition products was performed by using of X-ray powder diffraction and Mössbauer spectroscopy (Figure 1). The common decomposition products are metallic iron and spinel phase, while the other products include fayalite, cristobalite and cordierite for almandine; and pyroxene and anorthite for pyrope. The formation of this last component was enabled due to Ca content in pyrope.




Figure 1: Mössbauer spectra demonstrating the thermal decomposition of almandine (left) and pyrope (right) under reducing atmosphere.

Presenting author: Claudia Aparicio

Address: Šlechtitelů 11, 783 71 Olomouc, Czech Republic

FAX: +420 585634958

E-mail: claudia.aparicio01@upol.cz